

```

FORM RIBBON TAB "MachineTool"
IMPORT MACHINETOOL FILESELECTOR
"C:\Users\Antonin\Desktop\TOM\Databaze\Stroje\MCV1210_s_ramem.mtd"
FORM RIBBON TAB "Home"

FORM RIBBON BACKSTAGE CLOSE IMPORT MODEL FILEOPEN

"C:\Users\Antonin\Desktop\TOM\Databaze\Databaze_upinek_a_upinacu\SCHUNK Kontec
KSX.stl"
EXPLORER SELECT Model "Model\SCHUNK Kontec KSX" NEW
EDIT MODEL "SCHUNK Kontec KSX" SELECT ALL
EDIT MODEL "SCHUNK Kontec KSX" QUERY_MAKE_REF
Yes
FORM MODELTRANS EDIT MODEL "SCHUNK Kontec KSX" INTERACTIVE
TRANSFORM ANGLE "90,0"
TRANSFORM TYPE ROTATEX TRANSFORM MODEL "SCHUNK Kontec KSX"
TRANSFORM ANGLE "-90,0"
TRANSFORM TYPE ROTATEZ TRANSFORM MODEL "SCHUNK Kontec KSX"
TRANSFORM MOVE "-172"
TRANSFORM TYPE MOVE TRANSFORM MOVEY PRESET TRANSFORM MODEL "SCHUNK Kontec KSX"
MODELTRANS ACCEPT

EDIT MODEL "SCHUNK Kontec KSX" QUERY_UNMAKE_REF
Yes
FORM BLOCK
EDIT BLOCK COORDINATE WORLD
BLOCK ACCEPT
MODE WORKPLANE_CREATE ; SELECTION BOTTOM
FORM RIBBON TAB "MachineTool"
UNDRAW MACHINETOOL ;
DRAW MACHINETOOL ;
EXPLORER SELECT Workplane "Workplane\1" NEW
RENAME Workplane "1" "Zero vise point"
EXPLORER SELECT Model "Model\SCHUNK Kontec KSX" NEW
EDIT MODEL "SCHUNK Kontec KSX" QUERY_MAKE_REF
Yes
PICK -1636.34 -860.087 1636.34 860.087 220.292 -18.0692 13.3843 -0.0300662
-0.895502 0.44404 -0.0289086 0.444834 0.895146 0 -1436.02 -448.552 -1436.02
-448.552
FORM RIBBON TAB "Home"
FORM RIBBON TAB "MachineTool"
EDIT PAR SimulationState.ModelLocation "Zero vise point"
PICK -3195.98 -1679.86 3195.98 1679.86 1211.24 58.8939 295.692 -0.0300662 -0.895502
0.44404 -0.0289086 0.444834 0.895146 0 665.564 927.111 665.564 927.111
FORM RIBBON TAB "Home"

MODE WORKPLANE_CREATE ; INTERACTIVE POINT
PICK -398.605 -209.513 398.605 209.513 297.821 579.186 0.276502 -0.29305 -0.905128
0.308001 0.100806 0.291098 0.951367 0 -295.705 40.3113 -295.705 40.3113

```

```
EXPLORER SELECT Workplane "Workplane\1" NEW
MODE WORKPLANE_EDIT START "1"
MODE WORKPLANE_EDIT POSITION
MODE POSITION WORKSPACE WORLD
MODE POSITION CARTESIAN X "0"
MODE POSITION CARTESIAN Y "-23"
MODE POSITION CARTESIAN Z "196"
MODE POSITION BECOME
POSITION APPLY
```

```
MODE WORKPLANE_EDIT FINISH ACCEPT
```

```
RENAME Workplane "1" "Ustaveni do sveraku"
ACTIVATE WORKPLANE "Ustaveni do sveraku"
```