

- Controller Controller1
- Controller Fault Handler
- Power-Up Handler

Tasks

- MainTask
 - MainProgram
 - MainRoutine
 - automatika
 - Chyby
 - inicializace
 - instrukce
 - kontrola_Gkodu
 - posuv
 - reset_ALARM
 - tlacitka
 - SafetyTask
 - SafetyProgram
 - MainRoutine
- Unscheduled Programs / Phases

Motion Groups

- MotionGroup1
 - OsaX
 - OsaY
 - OsaZ
 - coordinate_axes
 - XY
- Ungrouped Axes

Add-On Instructions
























Data Types

- User-Defined
 - Alarm_DATA
 - manual
 - softovertravel
- Strings
 - STRING
- Add-On-Defined
- Module-Defined
 - AB:1756_DI:C:0
 - AB:1756_DNB_496Bytes:O:0
 - AB:1756_DNB_500Bytes:I:0
 - AB:1756_DNB_CommandRegister:O:0
 - AB:1756_DNB_StatusRegister:I:0
 - AB:1756_DNB_Status_128Bytes:S:0
 - AB:1756_DO:C:0
 - AB:1756_ENET_10SLOT:I:0
 - AB:1756_ENET_10SLOT:O:0
 - AB:1756_ENET_SLOT:I:0
 - AB:1756_ENET_SLOT:O:0
 - AB:1791DS_IB8XOB8_Safety1:I:0
 - AB:1791DS_IB8XOB8_Safety1:O:0
 - AB:1791DS_IB8XOB8_Safety2:O:0
 - AB:1791DS_IB8XOB8_Safety3:I:0
 - AB:1791DS_IB8XOB8_Safety5:I:0

Trends

I/O Configuration

- 1756 Backplane, 1756-A10
 - [0] 1756-L62S Controler1
 - [1] 1756-LSP Controler1:Partner
 - [2] 1756-ENBT/A ETHERNET
 - Ethernet
 - 1756-ENBT/A ETHERNET
 - 1756-ENBT/A ethernet2
 - 1756 Backplane, 1756-A10
 - [3] 1756-ENBT/A ethernet2
 - [7] 1756-OB16D Output
 - [8] 1756-IB16 Input
 - [3] 1756-DNB devicenet
 - DeviceNet
 - 13 1791DS-IB8XOB8/A Safety
 - 63 1756-DNB devicenet
 - [6] 1756-M08SE Kinetix_com
 - SERCOS Network
 - 11 2093-AC05-MP5 osaX
 - 13 2093-AMP5 OsaY
 - 14 2093-AMP5 OsaZ

Name	Value	Data Type	Scope
 Absprog <i>Absprog - MainProgram/automatika - 5(XIC), 6(XIC)</i> <i>Absprog - MainProgram/instrukce - *6(OTL)</i> <i>Absprog - MainProgram/kontrola_Gkodu - *0(OTU), 5(XIO)</i>	1	BOOL	Controler1
 Alarm_DATA_reset <i>Alarm_DATA_reset - MainProgram/reset_ALARM - 2(COP), 4(COP)</i> <i>Alarm_DATA_reset.ENABLE - MainProgram/reset_ALARM - *0(OTL)</i> <i>Alarm_DATA_reset.RESET - MainProgram/reset_ALARM - *1(OTL), *3(OTU)</i>		Alarm_DATA	Controler1
 alarm_Chya_vykonavani_inst vykonavani instrukce selhalo <i>alarm_Chya_vykonavani_inst - MainProgram/Chyby - *27(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_PROGRAM Chyba pri kontrole programu <i>alarm_PROGRAM - MainProgram/Chyby - *6(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_VRETEMO Porucha vretena <i>alarm_VRETEMO - MainProgram/Chyby - *5(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_XHome Chyba HOME osy X <i>alarm_XHome - MainProgram/Chyby - *21(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_XChyba Chyba osy X <i>alarm_XChyba - MainProgram/Chyby - *15(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_Xpres Osa X mimo rozsah <i>alarm_Xpres - MainProgram/Chyby - *9(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_YHome Chyba HOME osy Y <i>alarm_YHome - MainProgram/Chyby - *23(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_YChyba Chyba osy Y <i>alarm_YChyba - MainProgram/Chyby - *17(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_Ypres Osa Y mimo rozsah <i>alarm_Ypres - MainProgram/Chyby - *11(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_ZAVORA Naruseni opticke zavory <i>alarm_ZAVORA - MainProgram/Chyby - *7(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_ZHome Chyba HOME osy Z <i>alarm_ZHome - MainProgram/Chyby - *25(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_ZChyba Chyba osy Z <i>alarm_ZChyba - MainProgram/Chyby - *19(ALMD)</i>		ALARM_DIGITAL	Controler1
 alarm_Zpres Osa Z mimo rozsah <i>alarm_Zpres - MainProgram/Chyby - *13(ALMD)</i>		ALARM_DIGITAL	Controler1
 Automatika_ZAP <i>Automatika_ZAP - MainProgram/Chyby - 4(XIO)</i> <i>Automatika_ZAP - MainProgram/MainRoutine - 10(XIO), 11(XIO), 12(XIO), 3(XIO), 8(XIC), 9(XIO)</i> <i>Automatika_ZAP - MainProgram/tlacitka - *5(OTE)</i>	0	BOOL	Controler1
 CircuitReset <i>CircuitReset - SafetyProgram/  MainRoutine - 1(ESTOP), 2(LC)</i>	0	BOOL	SafetyProgram
 coordinate_axes <i>coordinate_axes - MainProgram/automatika - 7(MCLM)</i>		COORDINATE_SYSTEM	Controler1
 coordinate_MCCM <i>coordinate_MCCM[0] - MainProgram/automatika - *11(MCCM), *14(COP)</i> <i>coordinate_MCCM[0] - MainProgram/inicializace - *0(COP)</i> <i>coordinate_MCCM[0].ER - MainProgram/automatika - 13(XIC)</i> <i>coordinate_MCCM[0].PC - MainProgram/automatika - 12(XIC)</i>		MOTION_INSTRUCTION[2]	Controler1
 coordinate_MCLM <i>coordinate_MCLM[0] - MainProgram/automatika - *10(COP), *7(MCLM)</i> <i>coordinate_MCLM[0] - MainProgram/inicializace - *0(COP)</i> <i>coordinate_MCLM[0].ER - MainProgram/automatika - 9(XIC)</i> <i>coordinate_MCLM[0].PC - MainProgram/automatika - 8(XIC)</i>		MOTION_INSTRUCTION[24]	Controler1
 data <i>data - MainProgram/automatika - 11(MCCM), 7(MCLM)</i> <i>data[0] - MainProgram/inicializace - *0(MOV)</i> <i>data[0] - MainProgram/instrukce - *9(ADD), *9(MOV), *9(MUL), 9(ADD), 9(GRT), 9(LES)</i> <i>data[0] - MainProgram/kontrola_Gkodu - *12(MOV), *13(MOV), 0(MOV), 6(GRT), 6(LES)</i> <i>data[1] - MainProgram/inicializace - *0(MOV)</i> <i>data[1] - MainProgram/instrukce - *10(ADD), *10(MOV), *10(MUL), 10(ADD), 10(GRT), 10(LES)</i> <i>data[1] - MainProgram/kontrola_Gkodu - *12(MOV), *13(MOV), 0(MOV), 7(GRT), 7(LES)</i> <i>data[2] - MainProgram/inicializace - *0(MOV)</i> <i>data[2] - MainProgram/instrukce - *11(MOV), 11(GRT), 11(LES)</i> <i>data[2] - MainProgram/kontrola_Gkodu - *12(MOV), *13(MOV), 0(MOV), 8(GRT), 8(LES)</i>		REAL[3]	Controler1
 dekodovano	0	BOOL	Controler1

</

Controler1 - Tag Listing



























Controler1 (Controller)

11.5.2012 12:31:44

C:\Documents and Settings\student\Desktop\Kovar\9.5\CNC_9_5_Vizualizace.ACD
















<div><div></div><div>M</div></div>	'M'	STRING	Controler1
<div>M - MainProgram/instrukce - 1(FIND)</div>			
<div><div></div><div>MASX</div></div>		MOTION_INSTRUCTION	Controler1
<div>MASX - MainProgram/Chyby - *4(MAS)</div> <div>MASX - MainProgram/inicializace - *0(COP)</div>			
<div><div></div><div>MASY</div></div>		MOTION_INSTRUCTION	Controler1
<div>MASY - MainProgram/Chyby - *4(MAS)</div> <div>MASY - MainProgram/inicializace - *0(COP)</div>			
<div><div></div><div>MASZ</div></div>		MOTION_INSTRUCTION	Controler1
<div>MASZ - MainProgram/Chyby - *4(MAS)</div> <div>MASZ - MainProgram/inicializace - *0(COP)</div>			
<div><div></div><div>MCCMReset</div></div>		MOTION_INSTRUCTION	Controler1
<div>MCCMReset - MainProgram/automatika - 14(COP)</div> <div>MCCMReset - MainProgram/inicializace - 0(COP)</div>			
<div><div></div><div>MCLMreset</div></div>		MOTION_INSTRUCTION	Controler1
<div>MCLMreset - MainProgram/automatika - 10(COP)</div> <div>MCLMreset - MainProgram/inicializace - 0(COP)</div>			
<div><div></div><div>Meritko_X</div></div>	1.0	REAL	Controler1
<div>Meritko_X - MainProgram/instrukce - 9(MUL)</div>			
<div><div></div><div>Meritko_Y</div></div>	1.0	REAL	Controler1
<div>Meritko_Y - MainProgram/instrukce - 10(MUL)</div>			
<div><div></div><div>nahlizena_instrukce</div></div>	'G21'	STRING	Controler1
<div>nahlizena_instrukce - MainProgram/MainRoutine - *15(COP)</div>			
<div><div></div><div>offsetX</div></div>	116.73	REAL	Controler1
<div>offsetX - MainProgram/inicializace - *0(MOV)</div> <div>offsetX - MainProgram/instrukce - 9(ADD)</div> <div>offsetX - MainProgram/posuv - *10(MOV)</div>			
<div><div></div><div>offsetY</div></div>	66.78125	REAL	Controler1
<div>offsetY - MainProgram/inicializace - *0(MOV)</div> <div>offsetY - MainProgram/instrukce - 10(ADD)</div> <div>offsetY - MainProgram/posuv - *10(MOV)</div>			
<div><div></div><div>offsetZ</div></div>	39.205	REAL	Controler1
<div>offsetZ - MainProgram/inicializace - *0(MOV)</div> <div>offsetZ - MainProgram/instrukce - 11(SUB)</div> <div>offsetZ - MainProgram/posuv - *10(MOV)</div>			
<div><div></div><div>offsetZ_log</div></div>	70.795	REAL	Controler1
<div>offsetZ_log - MainProgram/instrukce - *11(SUB), 11(SUB)</div>			
<div><div></div><div>OsaX</div></div>		AXIS_SERVO_DRIVE	Controler1
<div>OsaX - MainProgram/Chyby - 4(MAS)</div> <div>OsaX - MainProgram/MainRoutine - 1(MASR), 13(MSF), 14(MAS), 3(MASR), 4(MSO), 5(MAH)</div> <div>OsaX - MainProgram/posuv - 0(MAJ), 1(MAJ), 2(MAS), 9(MSF)</div> <div>OsaX.ActualPosition - MainProgram/posuv - 10(MOV)</div> <div>OsaX.ActualVelocity - MainProgram/Chyby - 3(LIM)</div> <div>OsaX.AxisFault - MainProgram/Chyby - 14(EQU)</div> <div>OsaX.AxisHomedStatus - MainProgram/Chyby - 20(XIO)</div> <div>OsaX.DriveEnableStatus - MainProgram/MainRoutine - 5(XIC), 7(XIC)</div> <div>OsaX.NegSoftOvertravelFault - MainProgram/Chyby - 8(XIC)</div> <div>OsaX.PosSoftOvertravelFault - MainProgram/Chyby - 8(XIC)</div>			
<div><div></div><div>OsaY</div></div>		AXIS_SERVO_DRIVE	Controler1
<div>OsaY - MainProgram/Chyby - 4(MAS)</div> <div>OsaY - MainProgram/MainRoutine - 1(MASR), 13(MSF), 14(MAS), 3(MASR), 4(MSO), 5(MAH)</div> <div>OsaY - MainProgram/posuv - 3(MAJ), 4(MAJ), 5(MAS), 9(MSF)</div> <div>OsaY.ActualPosition - MainProgram/posuv - 10(MOV)</div> <div>OsaY.ActualVelocity - MainProgram/Chyby - 3(LIM)</div> <div>OsaY.AxisFault - MainProgram/Chyby - 16(EQU)</div> <div>OsaY.AxisHomedStatus - MainProgram/Chyby - 22(XIO)</div> <div>OsaY.DriveEnableStatus - MainProgram/MainRoutine - 5(XIC), 7(XIC)</div> <div>OsaY.NegSoftOvertravelFault - MainProgram/Chyby - 10(XIC)</div> <div>OsaY.PosSoftOvertravelFault - MainProgram/Chyby - 10(XIC)</div>			
<div><div></div><div>OsaZ</div></div>		AXIS_SERVO_DRIVE	Controler1
<div>OsaZ - MainProgram/Chyby - 4(MAS)</div> <div>OsaZ - MainProgram/MainRoutine - 1(MASR), 13(MSF), 14(MAS), 3(MASR), 4(MSO), 5(MAH)</div> <div>OsaZ - MainProgram/posuv - 6(MAJ), 7(MAJ), 8(MAS), 9(MSF)</div> <div>OsaZ.ActualPosition - MainProgram/posuv - 10(MOV)</div> <div>OsaZ.ActualVelocity - MainProgram/Chyby - 3(LIM)</div> <div>OsaZ.AxisFault - MainProgram/Chyby - 18(EQU)</div> <div>OsaZ.AxisHomedStatus - MainProgram/Chyby - 24(XIO)</div> <div>OsaZ.DriveEnableStatus - MainProgram/MainRoutine - 5(XIC), 7(XIC)</div> <div>OsaZ.NegSoftOvertravelFault - MainProgram/Chyby - 12(XIC)</div> <div>OsaZ.PosSoftOvertravelFault - MainProgram/Chyby - 12(XIC)</div>			
<div><div></div><div>P</div></div>	'P'	STRING	Controler1
<div>P - MainProgram/instrukce - 7(FIND)</div>			
<div><div></div><div>P101DateNeg01</div></div>	1	BOOL	SafetyProgram
<div>P101DateNeg01 - SafetyProgram/ MainRoutine - *0(OTE), 1(ESTOP)</div>			
<div><div></div><div>pocet_instrukci</div></div>	0	INT	Controler1
<div>pocet_instrukci - MainProgram/MainRoutine - *12(MOV)</div>			
<div><div></div><div>pokracovat_v_prog</div></div>	0	BOOL	Controler1
<div>pokracovat_v_prog - MainProgram/Chyby - 1(XIC)</div>			
<div><div></div><div>por_proh_ins</div></div>	0	INT	Controler1


RSLogix 5000


	por_proh_ins (Continued) <i>por_proh_ins - MainProgram/MainRoutine - 15(COP)</i>		
	Poradi_instrukce <i>Poradi_instrukce - MainProgram/automatika - *1(ADD), 1(ADD)</i> <i>Poradi_instrukce - MainProgram/Chyby - *1(SUB), 1(SUB)</i> <i>Poradi_instrukce - MainProgram/inicializace - *0(MOV)</i> <i>Poradi_instrukce - MainProgram/instrukce - 1(FIND), 10(MID), 11(MID), 12(MID), 3(STOR), 4(STOR), 5(FIND), 5(MID), 7(FIND), 7(MID), 8(FIND), 9(MID)</i> <i>Poradi_instrukce - MainProgram/kontrola_Gkodu - *0(MOV), *11(ADD), *12(MOV), *13(MOV), 0(MOV), 11(ADD), 2(MOV), 5(MOV), 6(MOV), 7(MOV), 8(MOV)</i> <i>Poradi_instrukce - MainProgram/MainRoutine - *11(MOV), 15(COP)</i>	0 INT	Controler1
	PoradiF <i>PoradiF - MainProgram/instrukce - *0(MOV), *5(FIND), 5(GRT), 5(MID)</i>	-1 INT	Controler1
	PoradiG <i>PoradiG - MainProgram/instrukce - *0(MOV), *1(FIND), 10(EQU), 11(EQU), 12(EQU), 4(EQU), 5(EQU), 6(EQU), 7(EQU), 8(EQU), 9(EQU)</i> <i>PoradiG - MainProgram/kontrola_Gkodu - 5(EQU)</i>	1 INT	Controler1
	PoradiM <i>PoradiM - MainProgram/instrukce - *0(MOV), *1(FIND), 13(EQU), 3(EQU)</i>	0 INT	Controler1
	PoradiP <i>PoradiP - MainProgram/instrukce - *0(MOV), *7(FIND), 7(MID)</i>	5 INT	Controler1
	PoradiR <i>PoradiR - MainProgram/instrukce - *0(MOV), *8(FIND), 12(GRT), 12(MID)</i>	-1 INT	Controler1
	PoradiX <i>PoradiX - MainProgram/instrukce - *0(MOV), *8(FIND), 9(GRT), 9(MID)</i>	-1 INT	Controler1
	PoradiY <i>PoradiY - MainProgram/instrukce - *0(MOV), *8(FIND), 10(GRT), 10(MID)</i>	-1 INT	Controler1
	PoradiZ <i>PoradiZ - MainProgram/instrukce - *0(MOV), *8(FIND), 11(GRT), 11(MID)</i>	-1 INT	Controler1
	Poradizavorka <i>Poradizavorka - MainProgram/instrukce - *0(MOV), *1(FIND), 2(EQU), 2(GRT)</i>	0 INT	Controler1
	pozice_X AliasFor: OsaX.ActualPosition Base Tag: OsaX.ActualPosition <i>pozice_X - MainProgram/posuv - 0(LES), 1(GRT), 2(GRT), 2(LES)</i>	116.73062 REAL	Controler1
	pozice_Y AliasFor: OsaY.ActualPosition Base Tag: OsaY.ActualPosition <i>pozice_Y - MainProgram/posuv - 3(LES), 4(GRT), 5(GRT), 5(LES)</i>	66.780624 REAL	Controler1
	pozice_Z AliasFor: OsaZ.ActualPosition Base Tag: OsaZ.ActualPosition <i>pozice_Z - MainProgram/posuv - 6(LES), 7(GRT), 8(GRT), 8(LES)</i>	29.215626 REAL	Controler1
	Pracpos <i>Pracpos - MainProgram/instrukce - *6(OTL), *6(OTU)</i>	0 BOOL	Controler1
	pripraveno <i>pripraveno - MainProgram/MainRoutine - *7(OTE), 8(XIC), 9(XIC)</i>	1 BOOL	Controler1
	probihajici_instrukce <i>probihajici_instrukce - MainProgram/MainRoutine - *15(COP)</i>	'G21' STRING	Controler1
	progexel <i>progexel - MainProgram/MainRoutine - *12(OTE), 12(XIO)</i>	0 BOOL	Controler1
	ProgMM <i>ProgMM - MainProgram/automatika - 5(XIC), 6(XIC)</i> <i>ProgMM - MainProgram/instrukce - *6(OTL)</i> <i>ProgMM - MainProgram/kontrola_Gkodu - *0(OTU), 5(XIO)</i>	1 BOOL	Controler1
	Program_ALARM <i>Program_ALARM - MainProgram/reset_ALARM - *2(COP), *4(COP)</i> <i>Program_ALARM.DISABLE - MainProgram/Chyby - 6(ALMD)</i> <i>Program_ALARM.ENABLE - MainProgram/Chyby - 6(ALMD)</i> <i>Program_ALARM.ENABLE - MainProgram/kontrola_Gkodu - *0(OTL), *12(OTU)</i>	Alarm_DATA	Controler1
	Program_OK <i>Program_OK - MainProgram/Chyby - 6(ALMD)</i> <i>Program_OK - MainProgram/inicializace - *0(OTU)</i> <i>Program_OK - MainProgram/kontrola_Gkodu - *0(OTU), *12(OTL), *13(OTU)</i> <i>Program_OK - MainProgram/MainRoutine - *12(OTU), 10(XIO), 8(XIC)</i>	1 BOOL	Controler1
	Programovani <i>Programovani - MainProgram/MainRoutine - 12(XIC)</i> <i>Programovani - MainProgram/tlacitka - *4(OTU)</i>	0 BOOL	Controler1
	R <i>R - MainProgram/instrukce - 8(FIND)</i>	'R' STRING	Controler1
	RealG <i>RealG - MainProgram/automatika - 3(EQU), 4(EQU), 5(EQU), 6(EQU)</i> <i>RealG - MainProgram/instrukce - *0(MOV), *4(STOR), 10(EQU), 11(EQU), 12(EQU), 5(EQU), 6(EQU), 7(EQU), 8(EQU), 9(EQU)</i> <i>RealG - MainProgram/kontrola_Gkodu - 5(EQU), 6(EQU), 7(EQU), 8(EQU)</i>	4.0 REAL	Controler1
	RealM <i>RealM - MainProgram/instrukce - *0(MOV), *3(STOR), 13(EQU)</i>	-1.0 REAL	Controler1
	RealR	0.0 REAL	Controler1


Controller1 - Tag Listing		Page 6	
Controler1 (Controller)		11.5.2012 12:31:46	
C:\Documents and Settings\student\Desktop\Kovar\9.5\CNC_9_5_Vizualizace.ACD			
<div><div></div><div><div>RealR (Continued)</div><div>RealR - MainProgram/automatika - 11(MCCM)</div><div>RealR - MainProgram/instrukce - *0(MOV), *12(STOR)</div></div></div>			
<div><div></div><div><div>RealX</div><div>0.0</div><div>RealX - MainProgram/instrukce - *9(STOR), 9(MUL)</div></div></div>	REAL		Controler1
<div><div></div><div><div>RealY</div><div>0.0</div><div>RealY - MainProgram/instrukce - *10(STOR), 10(MUL)</div></div></div>	REAL		Controler1
<div><div></div><div><div>RealZ</div><div>29.205002</div><div>RealZ - MainProgram/instrukce - *11(STOR), *11(SUB), 11(MOV), 11(SUB)</div></div></div>	REAL		Controler1
<div><div></div><div><div>reset_alarms</div><div>0</div><div>reset_alarms - MainProgram/MainRoutine - 16(XIC)</div></div></div>	BOOL		Controler1
<div><div></div><div><div>Reset_AUTOMATIKA</div><div>0</div><div>Reset_AUTOMATIKA - MainProgram/MainRoutine - 10(XIO), 11(XIC)</div><div>Reset_AUTOMATIKA - MainProgram/tlacitka - *6(OTE)</div></div></div>	BOOL		Controler1
<div><div></div><div><div>Reset_OS</div><div>0</div><div>Reset_OS - MainProgram/MainRoutine - 3(XIC)</div><div>Reset_OS - MainProgram/tlacitka - *0(OTE)</div></div></div>	BOOL		Controler1
<div><div></div><div><div>RUCNI_pohyb</div><div>0</div><div>RUCNI_pohyb - MainProgram/Chyby - 4(XIO)</div><div>RUCNI_pohyb - MainProgram/MainRoutine - 14(XIO), 3(XIO), 8(XIO), 9(XIC)</div><div>RUCNI_pohyb - MainProgram/tlacitka - *3(OTE)</div></div></div>	BOOL		Controler1
<div><div></div><div><div>Rychlopos</div><div>1</div><div>Rychlopos - MainProgram/instrukce - *6(OTL), *6(OTU)</div></div></div>	BOOL		Controler1
<div><div></div><div><div>Rychlost_posuvu</div><div>100</div><div>Rychlost_posuvu - MainProgram/automatika - 11(MCCM), 7(MCLM)</div><div>Rychlost_posuvu - MainProgram/instrukce - *6(MOV)</div><div>Rychlost_posuvu - MainProgram/kontrola_Gkodu - *12(MOV), *13(MOV), 0(MOV)</div></div></div>	DINT		Controler1
<div><div></div><div><div>Safety:I</div><div></div><div>Safety:I.Pt00Data - SafetyProgram/ MainRoutine - 0(XIO)</div><div>Safety:I.Pt01Data - SafetyProgram/ MainRoutine - 1(ESTOP)</div><div>Safety:I.Pt02Data - SafetyProgram/ MainRoutine - 2(LC)</div><div>Safety:I.Pt03Data - SafetyProgram/ MainRoutine - 2(LC)</div><div>Safety:I.Pt07Data - SafetyProgram/ MainRoutine - 5(XIC)</div></div></div>	AB:1791DS_IB8XOB8_Safety1:I:0		Controler1
<div><div></div><div><div>Safety:O</div><div></div><div>Safety:O.Pt00Data - MainProgram/MainRoutine - 8(XIC)</div><div>Safety:O.Pt00Data - SafetyProgram/ MainRoutine - *3(OTE)</div><div>Safety:O.Pt07Data - SafetyProgram/ MainRoutine - *4(OTE)</div></div></div>	AB:1791DS_IB8XOB8_Safety1:O:0		Controler1
<div><div></div><div><div>smer_KI</div><div>0</div><div>smer_KI - MainProgram/automatika - 11(MCCM)</div><div>smer_KI - MainProgram/instrukce - *12(MOV)</div></div></div>	INT		Controler1
<div><div></div><div><div>STAV</div><div>111</div><div>STAV - MainProgram/automatika - *10(MOV), *12(MOV), *13(MOV), *14(MOV), *2(MOV), *3(MOV), *4(MOV), *5(MOV), *6(MOV), *8(MOV), *9(MOV), 0(EQU), 1(EQU), 10(EQU), 11(EQU), 12(EQU), 13(EQU), 14(EQU), 2(EQU), 3(EQU), 4(EQU), 5(EQU), 6(EQU), 7(EQU), 8(EQU), 9(EQU)</div><div>STAV - MainProgram/Chyby - *1(MOV), *2(MOV), 1(EQU), 2(EQU), 26(EQU), 3(EQU)</div><div>STAV - MainProgram/inicializace - *0(MOV)</div><div>STAV - MainProgram/instrukce - *14(MOV)</div><div>STAV - MainProgram/kontrola_Gkodu - *12(MOV), *13(MOV)</div><div>STAV - MainProgram/MainRoutine - *11(MOV), *14(MOV)</div></div></div>	INT		Controler1
<div><div></div><div><div>STOP_Program</div><div>0</div><div>STOP_Program - MainProgram/automatika - 0(XIO), 10(XIO), 11(XIO), 14(XIO), 7(XIO)</div><div>STOP_Program - MainProgram/MainRoutine - 8(XIO)</div><div>STOP_Program - MainProgram/tlacitka - *14(OTE)</div></div></div>	BOOL		Controler1
<div><div></div><div><div>T_rozjezd</div><div></div><div>T_rozjezd - MainProgram/Chyby - *2(TON)</div><div>T_rozjezd.ACC - MainProgram/Chyby - *1(MOV)</div><div>T_rozjezd.DN - MainProgram/Chyby - 2(XIC)</div><div>T_rozjezd.PRE - MainProgram/Chyby - *1(MOV)</div></div></div>	TIMER		Controler1
<div><div></div><div><div>Tzpozdeni</div><div></div><div>Tzpozdeni - MainProgram/automatika - *4(TON)</div><div>Tzpozdeni.ACC - MainProgram/inicializace - *0(MOV)</div><div>Tzpozdeni.ACC - MainProgram/MainRoutine - *11(MOV)</div><div>Tzpozdeni.DN - MainProgram/automatika - 4(XIC)</div><div>Tzpozdeni.PRE - MainProgram/Chyby - 1(MOV)</div><div>Tzpozdeni.PRE - MainProgram/inicializace - *0(MOV)</div><div>Tzpozdeni.PRE - MainProgram/instrukce - *7(MUL)</div><div>Tzpozdeni.PRE - MainProgram/MainRoutine - *11(MOV)</div></div></div>	TIMER		Controler1
<div><div></div><div><div>V_pracposuv</div><div>30</div><div>V_pracposuv - MainProgram/instrukce - *5(STOD), 6(MOV)</div></div></div>	DINT		Controler1
<div><div></div><div><div>V_rychloposuv</div><div>100</div><div>V_rychloposuv - MainProgram/instrukce - 6(MOV)</div></div></div>	DINT		Controler1
<div><div></div><div><div>Vreteno</div><div>0</div><div>Vreteno - MainProgram/Chyby - *1(OTL), *3(OTU), *4(OTU), 0(XIC), 0(XIO), 2(XIC)</div><div>Vreteno - MainProgram/instrukce - *13(OTL), *13(OTU)</div><div>Vreteno - MainProgram/MainRoutine - *11(OTU), *13(OTU)</div><div>Vreteno_safety - SafetyProgram/ MainRoutine - 4(XIC)</div></div></div>	BOOL		Controler1
<div><div></div><div><div>Vreteno_ALARM</div><div></div><div>Vreteno_ALARM - MainProgram/reset_ALARM - *2(COP), *4(COP)</div><div>Vreteno_ALARM.ACK - MainProgram/Chyby - *0(OTE), 5(ALMD)</div><div>Vreteno_ALARM.DISABLE - MainProgram/Chyby - 5(ALMD)</div></div></div>	Alarm_DATA		Controler1


Controler1 - Tag Listing		Page 8	
Controler1 (Controller)		11.5.2012 12:31:47	
		C:\Documents and Settings\student\Desktop\Kovar\9.5\CNC_9_5_Vizualizace.ACD	
	y_MI_MAJ y_MI_MAJ[0] - MainProgram/posuv - *3(MAJ) y_MI_MAJ[0].ER - MainProgram/posuv - 5(XIC) y_MI_MAJ[0].IP - MainProgram/posuv - 5(XIC) y_MI_MAJ[1] - MainProgram/posuv - *4(MAJ) y_MI_MAJ[1].ER - MainProgram/posuv - 5(XIC) y_MI_MAJ[1].IP - MainProgram/posuv - 5(XIC)	MOTION_INSTRUCTION[2]	Controler1
	y_MI_MAS y_MI_MAS - MainProgram/posuv - *5(MAS) y_MI_MAS.EN - MainProgram/posuv - 3(XIO), 4(XIO) y_MI_MAS.ER - MainProgram/posuv - 9(XIC)	MOTION_INSTRUCTION	Controler1
	y_MI_MSF y_MI_MSF[0] - MainProgram/posuv - *9(MSF) y_MI_MSF[1] - MainProgram/inicializace - *0(COP) y_MI_MSF[1] - MainProgram/MainRoutine - *13(MSF)	MOTION_INSTRUCTION[2]	Controler1
	y_MI_MSO y_MI_MSO[0] - MainProgram/MainRoutine - *4(MSO)	MOTION_INSTRUCTION[2]	Controler1
	Y_SOT Y_SOT.MASR - MainProgram/MainRoutine - *1(MASR), *3(MASR) Y_SOT.MASR.DN - MainProgram/MainRoutine - 4(XIC)	softovertravel	Controler1
	YHome_ALARM YHome_ALARM - MainProgram/reset_ALARM - *2(COP), *4(COP) YHome_ALARM.ACK - MainProgram/Chyby - *22(OTE), 23(ALMD) YHome_ALARM.DISABLE - MainProgram/Chyby - 23(ALMD) YHome_ALARM.ENABLE - MainProgram/Chyby - 23(ALMD) YHome_ALARM.RESET - MainProgram/Chyby - 23(ALMD)	Alarm_DATA	Controler1
	YChyba_ALARM YChyba_ALARM - MainProgram/reset_ALARM - *2(COP), *4(COP) YChyba_ALARM.ACK - MainProgram/Chyby - *16(OTE), 17(ALMD) YChyba_ALARM.DISABLE - MainProgram/Chyby - 17(ALMD) YChyba_ALARM.ENABLE - MainProgram/Chyby - 17(ALMD) YChyba_ALARM.RESET - MainProgram/Chyby - 17(ALMD)	Alarm_DATA	Controler1
	yJOGminus 0 yJOGminus - MainProgram/posuv - 4(XIC), 5(XIC), 5(XIO) yJOGminus - MainProgram/tlacitka - *11(OTE)	BOOL	Controler1
	yJOGplus 0 yJOGplus - MainProgram/posuv - 3(XIC), 5(XIC), 5(XIO) yJOGplus - MainProgram/tlacitka - *10(OTE)	BOOL	Controler1
	Ypres_ALARM Ypres_ALARM - MainProgram/reset_ALARM - *2(COP), *4(COP) Ypres_ALARM.ACK - MainProgram/Chyby - *10(OTE), 11(ALMD) Ypres_ALARM.DISABLE - MainProgram/Chyby - 11(ALMD) Ypres_ALARM.ENABLE - MainProgram/Chyby - 11(ALMD) Ypres_ALARM.RESET - MainProgram/Chyby - 11(ALMD)	Alarm_DATA	Controler1
	Z 'Z' Z - MainProgram/instrukce - 8(FIND)	STRING	Controler1
	z_MAS z_MAS - MainProgram/inicializace - *0(COP) z_MAS - MainProgram/MainRoutine - *14(MAS)	MOTION_INSTRUCTION	Controler1
	z_MI_MAH z_MI_MAH[0] - MainProgram/inicializace - *0(COP) z_MI_MAH[0] - MainProgram/MainRoutine - *5(MAH) z_MI_MAH[0].DN - MainProgram/MainRoutine - 6(XIC)	MOTION_INSTRUCTION[2]	Controler1
	z_MI_MAJ z_MI_MAJ[0] - MainProgram/posuv - *6(MAJ) z_MI_MAJ[0].ER - MainProgram/posuv - 8(XIC) z_MI_MAJ[0].IP - MainProgram/posuv - 8(XIC) z_MI_MAJ[1] - MainProgram/posuv - *7(MAJ) z_MI_MAJ[1].ER - MainProgram/posuv - 8(XIC) z_MI_MAJ[1].IP - MainProgram/posuv - 8(XIC)	MOTION_INSTRUCTION[2]	Controler1
	z_MI_MAS z_MI_MAS - MainProgram/posuv - *8(MAS) z_MI_MAS.EN - MainProgram/posuv - 6(XIO), 7(XIO) z_MI_MAS.ER - MainProgram/posuv - 9(XIC)	MOTION_INSTRUCTION	Controler1
	z_MI_MSF z_MI_MSF[0] - MainProgram/posuv - *9(MSF) z_MI_MSF[1] - MainProgram/inicializace - *0(COP) z_MI_MSF[1] - MainProgram/MainRoutine - *13(MSF)	MOTION_INSTRUCTION[2]	Controler1
	z_MI_MSO z_MI_MSO[0] - MainProgram/MainRoutine - *4(MSO)	MOTION_INSTRUCTION[2]	Controler1
	Z_SOT Z_SOT.MASR - MainProgram/MainRoutine - *1(MASR), *3(MASR) Z_SOT.MASR.DN - MainProgram/MainRoutine - 4(XIC)	softovertravel	Controler1
	Zaloha_data Zaloha_data[0] - MainProgram/kontrola_Gkodu - *0(MOV), 12(MOV), 13(MOV) Zaloha_data[1] - MainProgram/kontrola_Gkodu - *0(MOV), 12(MOV), 13(MOV) Zaloha_data[2] - MainProgram/kontrola_Gkodu - *0(MOV), 12(MOV), 13(MOV)	REAL[3]	Controler1
	Zaloha_poradi_instrukce 0 Zaloha_poradi_instrukce - MainProgram/kontrola_Gkodu - *0(MOV), 12(MOV), 13(MOV)	INT	Controler1
RSLogix 5000			


	Zaloha_Rychlost_posuvu <i>Zaloha_Rychlost_posuvu - MainProgram/kontrola_Gkodu - *0(MOV), 12(MOV), 13(MOV)</i>	100	INT	Controler1
	Zalohovani <i>Zalohovani - MainProgram/inicializace - *0(OTL)</i> <i>Zalohovani - MainProgram/kontrola_Gkodu - *0(OTU), *12(OTL), *13(OTL), 0(XIC)</i>	1	BOOL	Controler1
	Zapis_offset <i>Zapis_offset - MainProgram/posuv - 10(XIC)</i>	0	BOOL	Controler1
	Zapnuti_os <i>Zapnuti_os - MainProgram/MainRoutine - 4(XIC), 5(XIO)</i> <i>Zapnuti_os - MainProgram/tlacitka - *1(OTE)</i>	0	BOOL	Controler1
	zavora <i>zavora - MainProgram/Chyby - 7(ALMD)</i> <i>zavora - MainProgram/MainRoutine - 14(XIC)</i> <i>zavora - SafetyProgram/  MainRoutine - *6(OTE)</i>	0	BOOL	Controler1
	Zavora_ALARM <i>Zavora_ALARM.DISABLE - MainProgram/Chyby - 7(ALMD)</i> <i>Zavora_ALARM.ENABLE - MainProgram/Chyby - 7(ALMD)</i> <i>Zavora_ALARM.RESET - MainProgram/Chyby - 7(ALMD)</i>		Alarm_DATA	Controler1
	zavorka <i>zavorka - MainProgram/instrukce - 1(FIND)</i>	'('	STRING	Controler1
	ZHome_ALARM <i>ZHome_ALARM - MainProgram/reset_ALARM - *2(COP), *4(COP)</i> <i>ZHome_ALARM.ACK - MainProgram/Chyby - *24(OTE), 25(ALMD)</i> <i>ZHome_ALARM.DISABLE - MainProgram/Chyby - 25(ALMD)</i> <i>ZHome_ALARM.ENABLE - MainProgram/Chyby - 25(ALMD)</i> <i>ZHome_ALARM.RESET - MainProgram/Chyby - 25(ALMD)</i>		Alarm_DATA	Controler1
	ZChyba_ALARM <i>ZChyba_ALARM - MainProgram/reset_ALARM - *2(COP), *4(COP)</i> <i>ZChyba_ALARM.ACK - MainProgram/Chyby - *18(OTE), 19(ALMD)</i> <i>ZChyba_ALARM.DISABLE - MainProgram/Chyby - 19(ALMD)</i> <i>ZChyba_ALARM.ENABLE - MainProgram/Chyby - 19(ALMD)</i> <i>ZChyba_ALARM.RESET - MainProgram/Chyby - 19(ALMD)</i>		Alarm_DATA	Controler1
	zJOGminus <i>zJOGminus - MainProgram/posuv - 7(XIC), 8(XIC), 8(XIO)</i> <i>zJOGminus - MainProgram/tlacitka - *13(OTE)</i>	0	BOOL	Controler1
	zJOGplus <i>zJOGplus - MainProgram/posuv - 6(XIC), 8(XIC), 8(XIO)</i> <i>zJOGplus - MainProgram/tlacitka - *12(OTE)</i>	0	BOOL	Controler1
	zkalibrovano <i>zkalibrovano - MainProgram/Chyby - 4(XIC)</i> <i>zkalibrovano - MainProgram/MainRoutine - *6(OTE), 2(XIC), 7(XIC)</i>	1	BOOL	Controler1
	zpozdeni_vereteno <i>zpozdeni_vereteno - MainProgram/instrukce - *7(STOR), 7(MUL)</i>	5.0	REAL	Controler1
	Zpres_ALARM <i>Zpres_ALARM - MainProgram/reset_ALARM - *2(COP), *4(COP)</i> <i>Zpres_ALARM.ACK - MainProgram/Chyby - *12(OTE), 13(ALMD)</i> <i>Zpres_ALARM.DISABLE - MainProgram/Chyby - 13(ALMD)</i> <i>Zpres_ALARM.ENABLE - MainProgram/Chyby - 13(ALMD)</i> <i>Zpres_ALARM.RESET - MainProgram/Chyby - 13(ALMD)</i>		Alarm_DATA	Controler1























0








(End)

0









9

EQU

Equal

Source A

Source B

PoradiG

1

1

EQU

Equal

Source A

Source B

RealG

4.0

0.0

GRT

Greater Than (A>B)

Source A

Source B

PoradiX

-1

2

EQU

Equal

Source A

Source B

RealG

4.0

1.0

EQU

Equal

Source A

Source B

RealG

4.0

2.0

EQU

Equal

Source A

Source B

RealG

4.0

3.0

MID

Middle String

Source

Qty

Start

Dest

instrukce[Poradi_instrukce]

??

9

PoradiX

inst[0]

'X0.0000 Y'

STOR

String to Real

Source

Dest

inst[0]

'X0.0000 Y'

RealX

0.0

MUL

Multiply

Source A

Source B

Dest

Meritko_X

1.0

RealX

0.0

data[0]

116.73

ADD

Add

Source A

Source B

Dest

offsetX

116.73

data[0]

116.73

data[0]

116.73

GRT

Greater Than (A>B)

Source A

Source B

data[0]

116.73

540

MOV

Move

Source

Dest

540

data[0]

116.73

LES

Less Than (A<B)

Source A

Source B

data[0]

116.73

0

MOV

Move

Source

Dest

0

data[0]

116.73

dekodovano

(L)

10

EQU

Equal

Source A PoradiG

1

Source B 1

EQU

Equal

Source A RealG

4.0

Source B 0.0

GRT

Greater Than (A>B)

Source A PoradiY

-1

Source B 2

EQU

Equal

Source A RealG

4.0

Source B 1.0

EQU

Equal

Source A RealG

4.0

Source B 2.0

EQU

Equal

Source A RealG

4.0

Source B 3.0

MID

Middle String

Source instrukce[Poradi_instrukce]

??

Qty 9

Start PoradiY

-1

Dest inst[1]

'Y0.0000 '

STOR

String to Real

Source inst[1]

'Y0.0000 '

Dest RealY

0.0

MUL

Multiply

Source A Meritko_Y

1.0

Source B RealY

0.0

Dest data[1]

66.78125

ADD

Add

Source A offsetY

66.78125

Source B data[1]

66.78125

Dest data[1]

66.78125

GRT

Greater Than (A>B)

Source A data[1]

66.78125

Source B 520

MOV

Move

Source 520

Dest data[1]

66.78125

LES

Less Than (A<B)

Source A data[1]

66.78125

Source B 0

MOV

Move

Source 0


Dest data[1]


66.78125


dekodovano


(L)


11
















12

















4

yJOGminus

y_MI_MAS.EN

GRT

Greater Than (A>B)

Source Apozice_Y

<OsaY.ActualPosition>

Source B66.78125

-10

MAJ

Motion Axis Jog

AxisOsaY

Motion Controly_MI_MAJ[1]

Direction1

Speed20

Speed UnitsUnits per sec

Accel Rate10

Accel UnitsUnits per sec2

Decel Rate10

Decel UnitsUnits per sec2

ProfileTrapezoidal

Accel Jerk10

Decel Jerk10

Jerk UnitsUnits per sec3

MergeEnabled

Merge SpeedProgrammed

<< Less

EN

DN

ER

IP

5

yJOGplus

y_MI_MAJ[0].IP

yJOGminus

y_MI_MAJ[1].IP

yJOGminus

GRT

Greater Than (A>B)

Source Apozice_Y

<OsaY.ActualPosition>

Source B66.78125

521

yJOGplus

LES

Less Than (A<B)

Source Apozice_Y

<OsaY.ActualPosition>

Source B66.78125

-11

yJOGplus

yJOGminus

y_MI_MAJ[0].ER

y_MI_MAJ[1].ER

MAS

Motion Axis Stop

AxisOsaY

Motion Controly_MI_MAS

Stop TypeJog

Change DecelNo

Decel Rate100

Decel Units% of Maximum

Change Decel JerkNo

Decel Jerk100

Jerk Units% of Maximum

<< Less


EN


DN


ER

IP


PC








4



(End)





Data type Name: Alarm_DATA

Description:

Size: 4 byte(s)

Name	Data Type	Style	Description
ACK	BOOL	Decimal	
RESET	BOOL	Decimal	
DISABLE	BOOL	Decimal	
ENABLE	BOOL	Decimal	

Data type Name: manual

Description:

Size: 20 byte(s)

Name	Data Type	Style	Description
HOME	BOOL	Decimal	
ACCEL	REAL	Float	
DECCEL	REAL	Float	
LEFT	BOOL	Decimal	
RIGHT	BOOL	Decimal	
SPEED	REAL	Float	

Data type Name: softovertravel

Description:

Size: 104 byte(s)

Name	Data Type	Style	Description
ClearSoftBits	DINT	Decimal	
MAJ_OFF_SOT	MOTION_INSTRUCTION		
MAS	MOTION_INSTRUCTION[2]		
MASR	MOTION_INSTRUCTION		
MSO	MOTION_INSTRUCTION		
NegMemory	BOOL	Decimal	
Ok_to_override	BOOL	Decimal	
OvertravelResetState	DINT	Decimal	
PosMemory	BOOL	Decimal	
SavedConfigFaults	DINT	Decimal	
SetSoft	DINT	Decimal	

Data type Name: STRING

Description:

Size: 88 byte(s)

Name	Data Type	Style	Description
LEN	DINT	Decimal	
DATA	SINT[82]	ASCII	